

Quick Start Guide - LMDVR Cameras

1. Connect your device to a power source (if your device doesn't have a power cord to plug into an outlet, there will be a battery for you to connect to the camera)

2. Power the device on using the included remote. Hold the A button for 2s and let go. The unit will vibrate for 1s and power on into standby mode.

3. Put your device into a recording mode using the buttons on the remote.

- 24/7 Recording : Hold B for 2s and let go. The device vibrates once quickly and enters 24/7 recording mode.

- To exit 24/7 recording mode, press B once again quickly. The device vibrates twice to indicate it is saving the video and returning to standby mode.

- Photo Capture: Press C once quickly to take a photo. The device vibrates once quickly to indicate it took a photo, and then returns to standby mode.

- Motion Detection: Press D once quickly. The device vibrates once and enters motion detection mode. The device will only record once motion is detected.

- To exit motion detection mode, press D once again quickly. The device vibrates twice to indicate it is saving the video and returning to standby mode.

- Power Off: While in Standby mode, hold the A button for 2 seconds. The device will power off. There will be no vibrations to indicate power off.

